

Phase transformations in steel

- The **microstructure and mechanical** properties of steel are controlled by the **phase constituents**
- The **phase constitution** on the other hand is controlled by the **phase transformations** occurring during processing and/or heat treatment
- For all practically important purposes of phase transformation in steels, the **parent phase is austenite**
- The transformation of steel can be either
Isothermal: Transformation of austenite by holding at a fixed temperature below A_{c1}
Continuous: Transformation of austenite when steel is being **continuously cooled**.

Austenite to ferrite transformation

- During equilibrium cooling (**very slow cooling as in phase diagram**) of hypoeutectoid steels austenite is transformed to proeutectoid ferrite between A_{c3} and A_{c1} temperatures
- The same transformation takes place isothermally, when hypoeutectoid steel is instantaneously cooled below A_{c1} (say to 600 °C) and held isothermally
- The $\gamma \rightarrow \alpha$ transformation is **diffusive** in nature and occurs by **nucleation and growth**.
- Nucleation occurs at grain boundaries and other structural defects.

Austenite to pearlite transformation

- Below the eutectoid temperature, austenite transforms to pearlite → knowledge from phase diagram
- The transformation occurs by nucleation and growth
- The temperature of γ -transformation strongly influences the pearlite interlamellar spacing (λ_p) → as transformation temperature ↓, λ_p ↓
- The lower the value of λ_p , the higher is the hardness of the steel → as the transformation temperature ↓, steel hardness ↑

Pearlite formed at 700 degree C → $\lambda_p = 10^{-3}$ mm, hardness 20 RC

Pearlite formed at 600 degree C → $\lambda_p = 10^{-4}$ mm, hardness 30 RC

Austenite to pearlite transformation




Photomicrograph of
coarse pearlite



Photomicrograph of
fine pearlite

Austenite to pearlite transformation

The kinetics of austenite → pearlite transformation follows a C-curve behavior



Austenite to pearlite transformation

- At **high temperatures** (just below A_{c1} , corresponding to low undercooling) the **nucleation rate is small but the growth rate is high**
- At **low temperatures** (corresponding to high undercooling) the **nucleation rate is high but the growth rate is small**
- In both these cases, the transformation rate is low
- The **maximum transformation rate is accomplished at intermediate temperatures** → C-shaped transformation curve

Austenite to martensite transformation

- Martensite (denoted as α') is a non-equilibrium structure which appears when the austenitized steel samples are rapidly cooled or quenched
- Being a non-equilibrium phase, martensite is not denoted on the Fe-Fe₃C metastable phase diagram



Martensite (Quenching)

X 700

Typical needle shaped
microstructure of martensite

Austenite to martensite transformation

- The transformation of austenite to martensite is **diffusionless** and shear-like in nature
- The cooling rate should be fast enough so that other competing transformations e.g. ferrite, pearlite or bainite do not occur
- During martensitic transformation, the FCC unit cell of austenite transforms to the **BCT (body centered tetragonal)** unit cell of martensite ➔ it is simply a **body centered cube, elongated along a direction**
- All the **carbon** atoms remain as **interstitial** impurity and constitute a supersaturated solid solution.

Austenite to martensite transformation

- The martensitic transformation is **athermal** in nature → it occurs **instantaneously** and at a very rapid speed
- The nucleation of martensite is heterogeneous and occurs at structural defects located at prior austenite grain boundaries
- For any steel the transformation starts and finishes at definite temperatures:

M_s : martensite start temperature


M_f : martensite finish temperature

Austenite to martensite transformation

The M_s and M_f temperatures are strongly dependent upon the C-concentration and alloying element content

Effect of alloying element on M_s temperature


$$M_s(^{\circ}C) = 539 - 463C - 30.4Mn - 17.7Ni - 12.1Cr - 7.5Mo$$



The M_f temperature typically ranges from 165 – 245 °C below the corresponding M_s temperature

Austenite to martensite transformation


- The transformation of austenite to martensite is associated with an extremely high increase of hardness → **of all phases of steel, martensite is the hardest**
- The **very high hardness** of martensite is attributed to the presence of **carbon at interstitial sites in the BCT lattice**.




- Tetragonality of the unit cell (the c/a ratio) increases with C-content. The corresponding severe lattice distortions results into a **highly strained unit cell** and corresponding high hardness.

BCT unit cell of martensite

Austenite to martensite transformation



Evolution of martensite
lattice parameters with C-
content



Evolution of martensite
hardness with C-content


Austenite to bainite transformation

- Bainite forms by the decomposition of austenite at temperatures **intermediate** to **pearlite** formation and **M_s -temperature**.
- Bainite forms by the growth of ferrite followed by the precipitation of cementite as a result of carbon diffusion.
- Depending upon the transformation temperature, the bainite formed may be classified as upper bainite and lower bainite, respectively.

Isothermal transformation diagram

- Isothermal transformation diagram (or **IT diagram**) also known as time-temperature-transformation diagram (or **TTT-diagram**) is a useful tool to study **non-equilibrium phase transformations** in steel
- In isothermal transformation after austenitizing, the steel is cooled to a temperature below A_{c1} and then held isothermally to study the phase transformations.
- Several samples cut from the same bar are austenitized and then put in a salt baths maintained at different sub A_{c1} temperatures. After holding for certain times, the samples are quenched and their microstructure and hardness are measured.

Isothermal transformation diagram



IT diagram for a eutectoid steel


Isothermal transformation diagram

- This particular diagram is only valid for eutectoid composition. For other compositions the IT plot will have different shapes
- Vertical axis of the diagram is temperature and the horizontal axis is time, in logarithmic scale
- The two solid C-shaped curves correspond to the start and end of austenitic transformation to pearlite.
- The dotted C-curve intermediate between the two solid curves corresponds to 50% of transformation.
- In the upper portion of the curve, the pearlite start curve asymptotically approaches the A_{c1} line at large times

Isothermal transformation diagram

- The two horizontal lines at the lower portion of the curve denote M_s and M_f temperatures, respectively.
- The phase markings denote the respective regions where each phase forms during the isothermal transformation of austenite.
- The **pearlitic nose** denotes the temperature at which the **maximum transformation rate** is obtained. Upper bainite forms just below the nose region.


IT diagram – structure development



Schematic study of the structure development is carried out by the 5 isothermally held samples (line 1 - 5)

IT diagram – structure development

Line 1




Isothermal transformation diagram

- Specimen 1 is rapidly cooled to 650 °C (a temperature rather close to A_{c1}), held there for 2000 sec. and then quenched to room temperature.
- The horizontal line crosses both the C-curve lines → all the austenite has been transformed to pearlite
- The final microstructure will be 100% pearlite
- As the transformation temperature is high, the pearlite will be coarse with a low hardness.

IT diagram – structure development

Line 2




Isothermal transformation diagram

- Specimen 2 is rapidly cooled to 550 °C, held there for 700 seconds and then quenched to room temperature
- The two C-curves are cut at a temperature close to the pearlitic nose
- The final microstructure will be 100% pearlite
- Due to the lower transformation temperature, the pearlite will be fine, resulting in a high hardness

IT diagram – structure development

Line 3




Isothermal transformation diagram

- Specimen 3 is rapidly cooled to 450 °C, held there for 300 seconds and then quenched to room temperature
- The two C-curves are cut at a temperature just below the pearlitic nose
- The final microstructure will be **completely bainitic**
- Due to the proximity of the transformation temperature to the pearlitic nose, the bainite is classified as **upper bainite**

IT diagram – structure development

Line 4




Isothermal transformation diagram

- Specimen 4 is rapidly cooled to 350 °C, held there for 200 seconds and then quenched to room temperature
- The two C-curves are cut at a temperature well below the pearlitic nose
- The final microstructure will be **completely bainitic**
- Due to the large distance of the transformation temperature to the pearlitic nose, the bainite is classified as **lower bainite**

IT diagram – structure development

Line 5



Isothermal transformation diagram

- Specimen 5 is rapidly cooled to room temperature
- The cooling curve does not cross any of the C-curves, but it crosses both the horizontal lines corresponding to M_s and M_f
- The final microstructure will be 100% martensite